



# iMac Intel 21.5" EMC 2428 Access Door Replacement

Remove the access door from your iMac Intel 21.5" EMC 2428.

Written By: Walter Galan



## INTRODUCTION

Use this guide to replace the access door on the bottom edge of your iMac.

---

### TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

## Step 1 — Access Door



- Lay your iMac face-down on a soft, clean surface as shown.
- ⚠ Be sure there isn't any dirt or debris on your work surface, as it may scratch the glass panel on the front of your iMac. We recommend placing a towel between the iMac and the work surface.
- Loosen the three Phillips screws securing the access door to the bottom edge of your iMac.
- ⓘ All three screws will remain captive in the access door.
- Remove the access door.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-18 08:37:32 AM.